

WARNING!

Damage **WILL** occur if tower is extended or retracted beyond indicators.



- 1) Tower is fully retracted when **ORANGE** indicators on bottom section & middle section are in line.



- 2) Tower is fully extended when **BLUE** indicators on bottom section & middle section are in line.



- 3) Pull **ORANGE** safety stop cable prior to retracting tower, or damage will occur.